



Laser Ratchet Orbit Block™ Fitting Instructions



1 Twist Dyneema® link to form an 'X' and secure in place using the supplied retainer clip.



2 Rubber stand-up boot
RF2454 to suit Series 40 Block
RF2455 to suit Series 55 Block

Slide the inverted rubber stand-up boot over the loop and slide it up the block as far as possible.

Pass an RF615 bow shackle through the Dyneema® link ensuring that the ratchet rotation is correct (with the rotation direction arrow on the block pointing toward the stern/back of the boat).



3 Tighten the shackle with a screwdriver making sure that the shackle is positioned with the pin at the bottom against the saddle (and so the 'bow' portion is over the Dyneema® link).



4 Roll down the boot and align it over the saddle/deck clip.



5 Thread through the mainsheet.



6 Go Sailing!