

Box Trailer Cover Kit Instructions

Package includes;

1 x Top Cover

2 x 6mm Shockcord 1.6M

2 x 6mm Shockcord 1M

4 x Parrell Beads 22mm

4x Plastic Hooks A.359

14 x Allen Hooks A..61

28 x no 6x 3/8" Countersunk S/S Screws.

Fitting Instructions

Box Trailer Sides

125mm to the top of the
box (not the frame) from
the top of the hook.



Box Trailer Ends



★ = Allen A..61 Hook

TRIDENT-UK.com

The Dinghy Shop on the Web